


Lux Sauna benches "Harmony"

(Lenght 1500, 1800, 2100, 2400)

**Please read the whole
manual before start!**


**All given measurements
are in millimeters!**




Lux Sauna benches "Harmony"

(Lenght 1500, 1800, 2100, 2400)




Details list





Lux Sauna benches "Harmony"



I





II



Lux Sauna benches "Harmony"



Benches with length of up to 1800 mm. DET 6a= 3pc.
Benches longer than 1800 mm. DET 6a= 4pc.

Use template to find washer and nut position!




2. III

NB! Place on flat, straight surface!






Lux Sauna benches "Harmony"

NB! Double-check legs position with template and then tighten the nuts. Legs must be on straight line, NOT twisted or curved!



Turn around!



3.

III

IV

Benches with length of up to 1800 mm. DET 6b= 3pc.
Benches longer than 1800 mm. DET 6b= 4pc.

DET 6b

DET 21

DET 5


DET 4

DET 9


DET 20

DET 11

Lux Sauna benches "Harmony"



I



II

